

NOTE: This instruction sheet is for informational purposes only. Your working environment may differ from what is shown in the pictures. Please determine the location of wiring and plumbing before you begin. It is your responsibility to ensure proper installation and, if in doubt, contact customer service. While our products are designed for homeowner installation, you assume all risk associated with the installation process. You may view Installation Videos at <https://closetvids.com>

# Valet Rod Installation



# STOP!



Watch the video at:  
**[www.closetvids.com](https://www.closetvids.com)**

# FASTENERS

**These are the fasteners used in the assembly of Perfect Spaces Storage Systems:**



Drawer Face Screw



Wood Screws  
(1¼", 2", 3")



Rafix Connector Stud



Sharpie  
(½" & ¾")



Shelf Pin



Pan Head Screw  
(5/8")



EZ Anchor



L-Bracket



Mending Plate



Euro Screws  
(Short / Long)



Breakaway Screws (Gold / Silver)

When purchasing your first closet you will receive a supply of fasteners adequate to complete the installation of your storage system. On your next closet order you will need to include a parachute bag stocked with a supply of fasteners. Please see the "Parachute Bags & Fasteners" guide/video for details.



**Need more installation information?**

Scan this QR code for detailed procedures and helpful technical tips in our full installation manual.

Disassemble the rod by pulling down on the black tab on the rear of the housing while extending the rod.



Determine where the unit is to be placed while being mindful of doors or other accessories that may interfere with its placement and usage. Align the housing with the front edge of your vertical panel and install a 5/8" sharpie screw in the front hole.



Level the unit and then install a second screw in the rear hole.



Slide the rod back into the housing.

